

-MDX 500- Firmware upgrade

Necessary material:

- MDX 500 with version 5.73 or later;
- USB 2.0 memory stick;
- Last firmware version for MDX 500;
- PC;



Note: If there are some programs stored at your MDX 500, please save it in your USB 2.0 memory stick before upgrading because during upgrading, programs stored at MDX will be deleted. You can recover from memory stick later.


For this, please follow MDX 500 user manual at "Programs" chapter.

Previous steps:


- Download last firmware version available for your field strength meter. You can find at: <http://www.ankaro.com>
- Unzip the file downloaded from the web site. It contains:
 - app_usb.bin

Upgrading:


1. Copy in the root directory of your USB 2.0 memory stick the file app_usb.bin;
2. Switch on MDX. Access to "Setup" menu → "System" → and go to "Firmware upgrade" option, but **DON'T** confirm this option with "OK".



3. In this moment, insert USB 2.0 memory stick into the field strength meter. If it has been inserted correctly and detected by the MDX 500, next screen will appear:



4. Confirm the "Firmware upgrade" option using "OK". Next screen will appear:



5. Once the upgrading has finished, the equipment will automatically re-boot. After this step, MDX 500 will have last firmware version installed.